

# User Manual: NexBot Drives 841-002 Parts Feeder

SKU: NXB-GEN-841-002 | Version: 1.0 | Brand: NexBot Robotics

## Table of Contents

1. Safety Information
2. Product Overview
3. Getting Started
4. Operation
5. Maintenance
6. Troubleshooting
7. Technical Specifications

## 1. Safety Information

**READ ALL SAFETY INSTRUCTIONS BEFORE OPERATION.** Failure to follow safety procedures may result in serious injury or equipment damage.

**DANGER:** ELECTRICAL HAZARD. Disconnect and lock out all power sources before servicing. This unit contains high voltage (120/240VAC) that can cause severe injury or death.

**WARNING:** CRUSH AND PINCH HAZARD. Keep hands, clothing, and tools away from the vibrating bowl, discharge track, and drive mechanism during operation.

**WARNING:** Unexpected motion can occur. Ensure the feeder is fully stopped and de-energized before attempting to clear part jams or perform maintenance.

**CAUTION:** The drive unit and base may become hot during extended operation. Allow the unit to cool before touching these surfaces.

**NOTICE:** The NexBot Drives 841-002 Parts Feeder is designed for specific part types. Introducing foreign objects or incorrect parts may damage the bowl and tooling.

## 2. Product Overview

NexBot Drives 841-002 Parts Feeder (NXB-GEN-841-002) is a parts feeders used in industrial robotics equipment where category-specific fit, electrical or mechanical compatibility, and predictable serviceability are important to buyers. The product should be understood as the exact component named by its category path, not as a complete robot or a generic service item. It supports installation, replacement, and maintenance workflows in robotic production cells by giving procurement and maintenance teams a clearly defined part class, relevant engineering specifications, and application context that matches the actual hardware being purchased.

## 3. Getting Started

### 1. Product Overview

The NexBot Drives 841-002 Parts Feeder (NXB-GEN-841-002) is a vibratory feeder designed to orient and feed individual components into an automated assembly process. It consists of a cast aluminum bowl mounted on a tuned steel base containing an electromagnetic drive. Its IP54 rating ensures protection against dust and splashing water in industrial environments.

### 2. Control Interface

The feeder is controlled via an external controller, typically a PLC or robot controller. The control interface allows for remote start/stop commands and variable amplitude adjustment to control the feed rate. Refer to your system's integration manual for specific command protocols.

### 3. Initial Part Loading

Before starting, fill the bowl with the designated parts. Do not overfill; the optimal part level is typically between 50% and 75% of the bowl's capacity to allow for proper movement and orientation. Ensure no foreign debris or incorrect part types are introduced.

## 4. Operation

### Normal Operation

Once integrated, the feeder will operate based on signals from the master control system. It will start feeding parts when commanded and stop when the command is removed or when a downstream sensor indicates a full track. Monitor the part level in the bowl and refill as needed to ensure continuous operation.

## Adjusting Feed Rate

The feed rate is controlled by adjusting the vibration amplitude via the external controller. Increase amplitude for a faster feed rate and decrease it for a slower rate. The optimal setting provides a consistent flow of correctly oriented parts without causing them to jump or become damaged.

**Tip:** Small, incremental adjustments are more effective than large changes. Allow the bowl to stabilize for several seconds after each adjustment to observe the true effect on part flow.

## Clearing Part Jams

If parts become jammed, immediately stop the feeder. For minor jams, a short burst of low-pressure compressed air may be sufficient. For major jams, de-energize and LOTO the machine before manually removing the obstruction with appropriate tools, taking care not to scratch the bowl surface.

## Shutdown Procedure

For a temporary stop, use the control system's stop command. For extended shutdown or maintenance, follow the full shutdown procedure which includes stopping the unit, then de-energizing and locking out the main electrical disconnect.

## 5. Maintenance Schedule

| Interval  | Task  | Notes   |
|-----------|---|---|
| Daily     | Visually inspect the bowl for foreign debris, part fragments, and excessive dust. Check that the discharge track is clear.  | Perform this check at the beginning of each shift.                        |
| Weekly    | Wipe down the cast aluminum bowl interior with a soft, lint-free cloth and an approved cleaning agent (e.g., isopropyl alcohol). Check all external mounting bolts on the steel base for tightness. | Do not use abrasive cleaners that could damage the bowl's surface finish. |
| Monthly   | Inspect all electrical connections for tightness and signs of wear or corrosion. Check the condition of control and power cables.   | This must be done with the power fully disconnected and locked out.       |
| Quarterly | Verify the tightness of the bolts securing the drive unit to the base and the bowl to the drive unit. Inspect the condition of the springs or elastomers in the drive unit.                         | Refer to the service manual for specific torque values.                   |
| Annually  | Perform a comprehensive inspection of the   | This service should be performed by a                                     |

| Interval | Task   | Notes                 |
|----------|--|-----------------------|
|          | electromagnetic drive coil and armature. Check for signs of overheating, cracking, or excessive wear. Verify grounding continuity. | qualified technician. |

## 6. Troubleshooting

| Symptom                                      | Possible Cause   | Solution  |
|--|--|---|
| Feeder does not vibrate                      | No power, blown fuse, faulty controller signal, or burned-out coil.  | Verify power is supplied and breaker is on. Check fuses in the control panel. Confirm run signal is being sent from PLC. If all else fails, test coil for continuity (power off). |
| Parts are not moving or moving too slowly    | Amplitude set too low, bowl is dirty or oily, incorrect spring gap, or bowl is overloaded with parts.          | Increase amplitude setting. Clean the bowl surface. Adjust spring gap per service manual. Reduce the quantity of parts in the bowl.   |
| Feed rate is inconsistent or erratic         | Loose mounting bolts, fluctuating line voltage, or damaged/worn springs in the drive unit.                     | Torque all mounting bolts for the base and bowl. Check for stable supply voltage. Inspect drive springs for cracks or wear and replace if necessary.                              |
| Excessive audible noise or rattling          | Loose bolts, foreign object in the drive unit, or incorrect tuning causing parts to jump excessively.          | Inspect and tighten all fasteners. Check for and remove any debris. Reduce vibration amplitude to achieve a smooth, flowing motion instead of a hopping one.                      |
| Parts are feeding upside down or misoriented | Incorrect tooling/guide setup, worn-out tooling, or feed rate is too high for the tooling to work effectively. | Verify tooling is installed correctly per the setup diagram. Inspect for worn surfaces on guides that may allow misfeeds. Reduce the feed rate.                                   |
| Parts are getting damaged or scratched       | Vibration amplitude is too high, or there are sharp edges on the bowl tooling or discharge track.              | Reduce vibration amplitude. Stop the feeder and carefully inspect all surfaces that contact the parts, deburring any sharp edges found.   |

| Symptom                         | Possible Cause  | Solution   |
|---------------------------------|---|--|
| Feeder overheats and shuts down | Poor ventilation around the drive unit, incorrect voltage, or a failing electromagnetic coil. | Ensure the area around the steel base is clear of obstructions to allow for air circulation. Verify the input voltage matches the unit's setting. If overheating persists, contact NexBot support. |

## 7. Technical Specifications

| Parameter         | Value                          | Unit |
|-------------------|--------------------------------|------|
| Weight            | 45.5                           | kg   |
| Material          | Cast Aluminum Bowl, Steel Base |      |
| Voltage           | 120/240VAC                     |      |
| IP Rating         | IP54                           |      |
| Country of Origin | KR                             |      |
| Dimensions        | 650 x 550 x 700 mm             |      |