

# User Manual: NexBot Drives 761-006 Multi-Part Maintenance Kit

SKU: NXB-KIT-761-006 | Version: 1.0 | Brand: NexBot Robotics

## Table of Contents

1. Safety Information
2. Product Overview
3. Getting Started
4. Operation
5. Maintenance
6. Troubleshooting
7. Technical Specifications

## 1. Safety Information

**READ ALL SAFETY INSTRUCTIONS BEFORE OPERATION.** Failure to follow safety procedures may result in serious injury or equipment damage.

**DANGER:** Isolate all hazardous energy before servicing NexBot Drives 761-006 Multi-Part Maintenance Kit; stored electrical or mechanical energy may remain present after shutdown.

**WARNING:** Operate NXB-KIT-761-006 only within its intended Wear Parts & Consumables > Robot Maintenance Kits > Scheduled Maintenance Kits duty profile and published specification limits.

**CAUTION:** Use only approved tools, mating parts, and installation hardware to prevent premature wear or unsafe operation.

**NOTICE:** Protect the product from contamination, impact, and environmental exposure beyond the documented enclosure rating during installation and service.

## 2. Product Overview

The NexBot Drives 761-006 is a multi-part maintenance kit designed to simplify the scheduled servicing of compatible NexBot industrial robot arms. This kit contains all the essential consumables and replacement items required for one complete preventative maintenance cycle, helping to maximize operational uptime and maintain the robot's specified performance and longevity. By bundling necessary components under a single part number, this kit streamlines the procurement process and ensures technicians have the correct items on hand when service is due. Each component in the 761-006 kit is manufactured to original equipment specifications, guaranteeing proper fit and function. Regular preventative maintenance using this kit helps to prevent unplanned downtime by addressing common wear items before they can impact production. The included components are selected to support the recommended 8,000-hour service interval, a critical milestone in the robot's lifecycle. Following the prescribed maintenance schedule is essential for preserving the robot's positioning accuracy and overall reliability in demanding industrial environments such as automated assembly, material handling, and machine tending. The kit provides a structured approach to maintenance, allowing for efficient and repeatable service procedures. All contents are packaged for easy identification and deployment in an industrial setting. Using genuine NexBot Drives maintenance kits is the most effective way to protect your robotics investment and ensure consistent, reliable operation throughout the life of the equipment. This kit is specifically intended for use by trained service personnel following the procedures outlined in the official NexBot service manual for the corresponding robot series.

## 3. Getting Started

### 1. Confirm product identity

Verify the installed item is NexBot Drives 761-006 Multi-Part Maintenance Kit with SKU NXB-KIT-761-006. Cross-check the unit against project documentation before applying power or connecting it to the host system.

### 2. Review operating context

Understand how the product is used within the Wear Parts & Consumables > Robot Maintenance Kits > Scheduled Maintenance Kits workflow, including any upstream and downstream dependencies, service intervals, and operator responsibilities.

### 3. Complete initial startup

Power up the unit under controlled conditions, observe indicator states, and verify the product initializes cleanly with the expected site-rated supply operating setup.

## 4. Operation

### Normal operation

Run NexBot Drives 761-006 Multi-Part Maintenance Kit within the documented workload, environmental, and service conditions. Track alarms, unusual noise, heat, or vibration so corrective action can be scheduled before unplanned downtime occurs.

### Interface and controls

Use the supported electrical and control interfaces to commission, monitor, and troubleshoot the device. Validate all signal mappings and control behavior after maintenance or part replacement.

**Tip:** Capture a baseline of healthy status indicators after commissioning so later diagnostics can be compared quickly.

## Load and application limits

Keep the product within the published ratings for speed, force, load, and environmental exposure. Where applicable, confirm mounting, routing, and attached tooling do not compromise access, cooling, or serviceability.

## Change management

Whenever hardware, firmware, wiring, or connected tooling changes, repeat the relevant verification and commissioning checks before returning the equipment to production service.

**Tip:** Update maintenance records immediately after any wiring, parameter, or parts change.

## 5. Maintenance Schedule

Interval	Task	Notes
Daily	Inspect NexBot Drives 761-006 Multi-Part Maintenance Kit for visible wear, damage, contamination, loose hardware, and abnormal status indicators.	Record any abnormalities before the next production cycle begins.
Monthly	Verify mounting integrity, connector condition, and cable routing or strain relief points.	Retorque or reseal hardware only to the documented service specification.
Quarterly	Review diagnostic logs, event history, and operational trends for early signs of degradation.	Escalate recurring warnings before they develop into hard faults.
Annually	Perform a full service inspection covering mechanical condition, electrical connections, and functional verification.	Coordinate annual service with planned downtime to minimize production disruption.

## 6. Troubleshooting

Symptom	Possible Cause	Solution
Unit does not initialize or remain ready	Incoming supply, controls wiring, or commissioning parameters do not match the documented site-rated supply configuration.	Verify power quality, wiring continuity, protective devices, and startup parameters before restarting the unit.
		Inspect physical connections, confirm interface settings, and

Symptom	Possible Cause	Solution
Intermittent communication or status loss	Loose connectors, damaged cabling, or interface mismatch.	replace damaged cables or connectors as needed.
Unexpected wear, vibration, or overheating	Mechanical loading, contamination, misalignment, or duty cycle exceeds the intended application conditions.	Inspect the installation, restore proper alignment and cooling, and verify the product is being used within its published operating limits.
Connected equipment performance is inconsistent	The installed product is not configured correctly for the host system or compatible robot series (R-10, R-20, R-50).	Validate the configuration, confirm compatibility, and rerun the functional verification procedure after any corrections.

## 7. Technical Specifications

Parameter	Value	Unit
Weight	4.5	kg
Country of Origin	SE	
Dimensions	450 x 300 x 200 mm	